



UAS Operations Manual

Updated 04-28-2026

Table of contents

- 1. General Procedures.....(2)
- 2. Flight Planning/Preparation.....(2)
- 3. Weather.....(2)
- 4. Site Selection..... (3)
- 5. Flight Team Briefing..... (3)
- 6. Accident Reporting.....(4)
- 7. Inspection and Maintenance..... (4)
- 8. Pre Flight Checklist.....(4)
- 9. Emergency Procedures.....(7)
- 10. Theory of Operation.....(9)
- 11. Battery Charging.....(13)
- Glossary of Terms.....(17)

APPENDICES

- A. AgBOT Drone Procedures.....(18)
- B. ICAW (Instructions for Continued Airworthiness).....(21)
- C. Component Limits.....(27)
- D. Wiring Diagrams and Schematics.....(28)

Limitations
Liabilities

Disclaimers

Disclaimer:

This document is provided for reference purposes only. Information contained herein may not apply to all aircraft configurations or operating conditions. Operators are responsible for ensuring compliance with applicable regulations and for consulting the aircraft manufacturer for configuration-specific procedures, limitations, and operational guidance.

This document provides baseline operational guidance. Operators may supplement procedures as required for specific missions but shall not remove or reduce existing requirements. Additional procedures may be necessary based on mission, configuration, or operating conditions.

1. General Procedures

- 1.1. US Airworthiness Requirements – Owner/Operator responsible for continued Airworthiness
- 1.2. UAS Registration and Markings –Owner Operator responsible for UAS registration and RID
- 1.3. UAS RID (Remote ID) - Module installed, enabled, registered by owner operator
- 1.4. UAS Control Frequency – In Compliance with FCC or local governing agency
- 1.5. Manufacture Manuals – UAS To Be Operated in Accordance with UAS Operation Manuals
- 1.6. Flight Team Members
 - 1.6.1. Pilot – PIC, Current Part 107
 - 1.6.2. Visual Observer – Knowledge of role
 - 1.6.3. Camera Operator – Able to take over control if pilot incapacitated -Current Part 107
 - 1.6.4. System Engineer/Assistant - Knowledge of frequency and voltage monitoring. Assist in preparation and crowd control.

2. Flight Planning/Preparation

- 2.1. Access feasibility of flight
- 2.2. Assessment of Proposed Operating Site
- 2.3. Pre-Notification – Verify if Any NOTAMS
- 2.4. FAA/LAANC Authorization, coordination with FAA/FISDO or governing body
- 2.5. Site Permissions – Obtain from landowners for takeoff/landing

- 2.6. Proximity to Air Traffic Control
- 2.7. Documentation

3. **Weather**

- 3.1. Wind Speeds - Do not exceed over 30 mph winds or gust spreads of 10mph or more.
- 3.2. Precipitation - Do not fly in rain, if flight encounters rain return to launch as soon as practical. The airframe and motors are water resistant and most likely will not create an emergency however it may affect performance.
- 3.3. Temperature - Temperatures above 95 F (35C) are allowed however flight time and engine performance may be reduced. Limit flight time as much as practical and keep an eye on Motor and ESC temperature. If the motor reaches over 250 degrees at landing, pause flight and allow Motors and ESC's to cool. Motor temperatures over 180C can damage the motor.

Temperature- Temperatures below 35F 2C are allowed, however performance can be affected. The biggest concern for low temperatures are poor battery performance, and plastic parts becoming more brittle. Keep batteries warm at or around 60F 15C. Inspect key structural plastic components for cracks or chips.

- 3.4. Density Altitude - As Density altitude increases, aircraft performance decreases, please mind payload and amperage for flights above 5000 feet density altitude. Expect lower flight times and higher current draw.
- 3.5. 500 below ceiling, 2,000 horizontal from cloud, 3 miles visibility

4. **Site Selection**

- 4.1. Sterile Area and Airspace Control
- 4.2. Only flight members in controlled area
- 4.3. Separation Distances - Determined by PIC
- 4.4. Ground Inspections – Wires, Guidelines, non-essential personnel
- 4.5. Cordoned off from public – tape, cones, signs
- 4.6. 500 feet from non-participating persons
- 4.7. Consent from those closer than 500 feet
- 4.8. Extra security personnel as needed
- 4.9. See-and-Avoid / Visual Line of Sight - Mandatory
- 4.10. Notification of Operations - Local Sheriff, police, fire, gov't officials – permissions/permits as required

5. **Flight Team Briefing**

- 5.1. Take-Off and Landing Zones – Determined before flight

- 5.2. Normal Flight Operations –
 - 5.2.1. Max Speed -
 - 5.2.2. Altitude -
 - 5.2.3. Reserve Power – 5 Minutes or follow manufacturers guidelines - See Appendix B
- 5.3. Flight Team Member Positioning
- 5.4. Roles and responsibility of team
- 5.5. Communication Plan
 - 5.5.1. Two-way radio and/or cell phone
- 5.6. Contingency Plan
 - 5.6.1. Abort Parameters
 - 5.6.2. Threats to Mission
 - 5.6.3. Recovery
- 5.7. Emergency Procedures
 - 5.7.1. All other aircraft have right of way and all flights are to remain within line of sight of the UAS pilot and or Visual Observer.
 - 5.7.2. Inform Air Traffic Control if an Emergency
 - 5.7.3. Seek Medical Attention if Required
6. **Accident Reporting**
 - 6.1. FAA Reporting – Report within 24 hours or abide by local governing law
 - 6.2. NTSB Reporting - Or local governing body
 - 6.3. Local Regulations
7. **Inspection and Maintenance Records –**
 - 7.1. Electronic Record Keeping – OK, if stored on appropriate app/software
 - 7.2. Develop an organization level standard operating procedure, specific for your intended use of the aircraft.
 - 7.3. Please log: flight location, duration, mission type, takeoffs/landings, battery changes, Day/night, BVLOS, abnormalities.
8. **Pre Flight Checklist: (General)**
 - 8.1. Visual Condition Inspection of the UAS components;
 - 8.2. Airframe Structure (Including undercarriage), all flight control surfaces, and linkages;
 - 8.3. Registration markings, for proper display and legibility;
 - 8.4. Moveable control surfaces(s), including attachment points;
 - 8.5. Servo motors, including attachment points;
 - 8.6. Propulsion system, including power plant(s), rotor(s), ducted fan(s), etc.;
 - 8.7. Verify all systems (e.g., aircraft and control unit) have an adequate energy supply for the intended operation and are functioning properly;

- 8.8. Avionics, including control link transceiver, communication/navigation equipment, and antennas;
- 8.9. Calibrate UAS as required per UAS manual;
- 8.10. Control link transceiver, communication/navigation data link transceiver, and antennas;
- 8.11. Display panel, if used, is functioning properly
- 8.12. Check ground support equipment, including take off and landing systems, for proper operation;
- 8.13. Check that control link correct functionality is established between the aircraft and control station
- 8.14. Check for correct movement of the control surfaces using the control station;
- 8.15. Check onboard navigation and data links;
- 8.16. Check flight termination system and emergency equipment if installed;
- 8.17. Check batteries levels for aircraft and control station;
- 8.18. Check batteries are secure and will not move during flight or turbulence.
- 8.19. Check that any equipment and payloads are securely attached;
- 8.20. Verify communications with UAS and that UAS has acquired GPS location for at least 4 satellites;
- 8.21. Start the UAS propellers to inspect for any imbalance or irregular operation
- 8.22. Verify all controller operation for heading and altitude, including; IMU, gyros, compass and GPS;
- 8.23. If required by flightpath walkthrough, verify any noted obstructions that may interfere with the UAS;
- 8.24. Use PIC discretion to avoid potential RF interference;
- 8.25. Ensure to abide any other supplemental operational guidelines for both aircraft, payloads and ground equipment.

8.26. Aircraft to Computer Connection:

- 8.26.1. First time use of BOT may require computer configuration to connect, once this has been established the computer and aircraft will maintain these settings unless altered. To establish drone and computer communication via USB, If this process doesn't work then Go in this order,Read through first before doing,
- 8.26.2. -Connect USB cable to drone
- 8.26.3. -Turn on controller (if needed, you can power aircraft only for this if desired)
- 8.26.4. -Turn on aircraft
- 8.26.5. -Let aircraft boot up

- 8.26.6. -If engines are making an arming tone, push engine safety switch to temporarily arm the motors (aircraft is safe as you still have to arm autopilot to start engines), motors go through a tone sequence, then go silent, push motor arm safety switch to disarm motors. (Motor arm safety switch flashes red when disarmed)
- 8.26.7. -Connect USB cable to computer
- 8.26.8. -Open device manager and find the com port your drone is using. (To do this plug in and unplug the usb while you are looking at Com Ports on the Device Manager tree, when the USB is plugged you should see this on the Com Port tree and it will give you a number associated with that Com Port. This will be the com port you select in Mission Planner, this is only done once to verify after that you can use Mission Planner to detect the com port in the same fashion as before on the device manager.)
- 8.26.9. -Open Mission Planner
- 8.26.10. -In the upper right corner of Mission Planner are drop down boxes, one labeled Com Port another Baud rate. When using USB we use a Baud of 115200, when using Data link its 57600.
- 8.26.11. -With Drone USB connected Mission Planner open, select the com port number and the baud rate
- 8.26.12. -Click Connect, you should see the screen flicker and a box opens up with a green bar to show connection and parameter download, once Parameters are loaded the screen will come alive and you are connected.
- 8.26.13. -If it stalls out and doesn't connect we need to troubleshoot Device driver, com port, speed and sometimes a bad USB cable. You can also try connecting directly to the side of the autopilot, do that if external USB port may be suspect. If Autopilot works and external USB does not we may have bad wiring or autopilot connection/configuration.

8.27. Camera/Trigger:

8.27.1. Camera and Trigger Theory of Operation

- 8.27.1.1. The aircraft has the ability to carry a multitude of different cameras and bind to their specific methods of capturing images. It is important to note that not all cameras are the same so it is important to understand the specific setup to your drone/camera system. Each camera can have a different field of view and time delay between captures. Make sure the flight mission made to map or autotrigger the camera meet the minimum requirements of the camera's ability. Flights that are low or too fast may not give enough time for the camera to reset and get ready for another picture, this often gets confused with "it failed to trigger". The triggers are there but the camera can't keep up.

- 8.27.1.2. **Camera Trigger workflow.** To enable the camera to remotely trigger by the pilot manually or automatically via “do_set_cam_trig_dist” command we first must understand the components and configuration in the system.
 - 8.27.1.2.1. **Camera-** The camera must be setup for a remote PWM input camera trigger. Check the manual of the camera to see how your specific camera is to be setup for PWM trigger input.
 - 8.27.1.2.2. **Autopilot-** The aircraft must be configured via Mission planner to enable the output of the autopilots camera trigger feature. There are a lot of ways to configure your autopilot to output a camera trigger. The AgBot is standard using PWM from 1100us to 1900us for 1 second (1/10s). RC 9 is set to camera trigger servo out. This output can be tested and verified using [Mission Planner](#). On the extended tuning page RC7 must be set to Cam Trigger
 - 8.27.1.2.3. **Aircraft Remote-** The remote controller must be setup as well to send a signal from a switch to the autopilot RC7 cam trigger input. Switch C or Switch B is often set to Channel 7 output.
 - 8.27.1.2.4. **Wiring-** Wiring from camera to autopilot is critical. It is possible for the wiring from the autopilot to the camera to be disturbed, damaged, or simply disconnected. Refer to appendix D for wiring schematics.

9. Emergency Procedures:

9.1. Fly Aways

- 9.1.1. Maintain visual contact;
- 9.1.2. Verify remote controller is powered on;
- 9.1.3. Toggle flight modes to gain control;
- 9.1.4. If unable to establish a link, continue to maintain visual sight of the UAS and update pertinent authorities.

9.2. Loss of GPS

- 9.2.1. If GPS signal is lost in flight, return to home and intelligent flight modes will be unavailable;
- 9.2.2. If UAS is flying erratically but still linked, switch modes from GPS to a manual flight mode;
- 9.2.3. Continue flight without GPS, Pilot the UAS to a safe LZ

9.2.4. Perform a manual landing and shut down.

9.3. **Low Battery**

9.3.1. Maintain visual contact with the UAS

9.3.2. Immediately return UAS to you for landing

9.3.3. If unable to return home, use onboard cameras to spot the closest suitable landing zone.

9.3.4. If unable to land before loss of power, PIC has discretion whether to deploy emergency parachute or not based on environmental and safety factors.

9.4. **Battery Fire**

9.4.1. Execute flight termination procedures

9.4.2. If unable to land before loss of power, PIC has discretion whether to deploy emergency parachute or not based on environmental and safety factors.

9.4.3. Use of Haltron and CO2 Fire extinguishers preferred.

9.4.4. If possible, allow a safe amount of time (approximately 30 min) to pass before attempting to salvage or clean up any wreckage.

9.5. **Lost Link**

9.5.1. Maintain visual contact with UAS

9.5.2. Verify remote controller is powered on;

9.5.3. Move towards UAS if possible;

9.5.4. If unable to re-establish link: continue to maintain visual with UAS, update ATC or pertinent authority with position of UAS

9.6. **Collision**

9.6.1. Immediately release all control sticks;

9.6.2. If UAS regains control, maneuver the UAS away from the object and return the UAS as safely as possible;

9.6.3. If UAS does not regain stability, it is the PIC's discretion as to whether or not to deploy the emergency parachute and/or initiate manual motor shut down to reduce the impact speed.

9.7. **Loss of Control Surface or Power Plant**

9.7.1. Make any and all attempts to steer drone to nearest emergency LZ;

9.7.2. PIC discretion to deploy parachute or utilize emergency equipment;

- 9.7.3. If UAS does not regain stability, it is the PIC's discretion as to whether or not to deploy an emergency parachute and/or initiate manual motor shut down to reduce the impact speed.

*All parachute systems will be operated in accordance with the manufacturers guidelines.

10. Theory of Operation:

10.1. Auto Pilot

10.1.1. The autopilot is a real-time embedded flight control system responsible for stabilizing, navigating, and managing an unmanned aircraft. Using inertial sensors (gyroscopes, accelerometers, and magnetometers), barometric altitude, GNSS positioning, and optional airspeed or vision inputs, the autopilot continuously estimates the vehicle's attitude, position, and velocity. These estimates are processed through control algorithms that compare the current state to pilot commands or mission objectives, generating control outputs to motors and control surfaces to maintain stability and follow commanded flight paths. The system supports both manual and autonomous operation, including failsafe logic to handle signal loss, sensor faults, or power anomalies, ensuring predictable and recoverable behavior across all flight modes.

10.1.2. Flight Modes

- 10.1.2.1. Flight modes determine how the autopilot stabilizes, navigates, and responds to pilot inputs. Each mode applies different control logic using onboard sensors and navigation data. Mode availability and behavior depend on aircraft configuration and autopilot parameters.
- 10.1.2.2. The most commonly programmed flight modes on the controller are Loiter, Altitude Hold, and Auto. Additional flight modes may be enabled or selected through Mission Planner.

10.1.3. Modes

- 10.1.3.1. Loiter
- 10.1.3.1.1. Loiter mode provides position, altitude, and attitude stabilization.
- 10.1.3.1.1.1. Aircraft maintains geographic position using GNSS data
- 10.1.3.1.1.2. Altitude is automatically controlled
- 10.1.3.1.1.3. Roll, pitch, and yaw are stabilized by the autopilot
- 10.1.3.1.1.4. Pilot input commands velocity and direction rather than direct attitude

- 10.1.3.1.1.5. Loss or degradation of GNSS may result in degraded performance or automatic mode fallback, depending on configuration.
- 10.1.3.2. Altitude Hold
 - 10.1.3.2.1. Altitude Hold mode maintains altitude while allowing manual lateral control.
 - 10.1.3.2.1.1. Autopilot controls vertical thrust to maintain altitude
 - 10.1.3.2.1.2. Pilot directly controls roll, pitch, and yaw
 - 10.1.3.2.1.3. GNSS position hold is not active
 - 10.1.3.2.1.4. Aircraft will drift with wind if no corrective input is applied
 - 10.1.3.2.1.5. This mode relies on barometric and inertial sensors for altitude reference.
 - 10.1.3.3. Auto
 - 10.1.3.3.1. Auto mode executes a preloaded mission.
 - 10.1.3.3.2. Aircraft follows programmed waypoints and commands
 - 10.1.3.3.3. Navigation, altitude, and speed are controlled by the autopilot
 - 10.1.3.3.4. Pilot retains the ability to override by switching flight modes
 - 10.1.3.3.5. Mission execution depends on valid navigation and sensor data
 - 10.1.3.3.6. Auto mode shall only be used with a verified mission and appropriate operational planning.
- 10.1.4. RTL
 - 10.1.4.1. Return to Launch (RTL) mode commands the aircraft to autonomously return to the recorded launch point.
 - 10.1.4.1.1. Aircraft navigates to the launch location using GNSS data
 - 10.1.4.1.2. Altitude behavior is controlled by configured RTL parameters
 - 10.1.4.1.3. Autopilot maintains stabilized flight during return
 - 10.1.4.1.4. Upon arrival, the aircraft will loiter, descend, or land based on configuration
 - 10.1.4.1.5. RTL may be initiated manually by the pilot or automatically due to predefined conditions such as loss of control link, low battery, or failsafe events.
 - 10.1.4.1.6. Proper RTL operation requires a valid home position and reliable navigation data. Degraded GNSS or sensor data may affect RTL performance.

10.2. Airframe

- 10.2.1. A multirotor airframe generates lift and control through multiple fixed-pitch, independently driven rotors arranged symmetrically around the center of mass. Vertical lift is produced by increasing rotor speed,

while attitude and directional control are achieved by varying the relative speeds of opposing rotors to create differential thrust and torque. Roll and pitch are controlled by increasing thrust on one side of the airframe while decreasing it on the opposite side, and yaw is controlled by balancing the counter-rotational torque between clockwise and counter-clockwise propeller pairs. The rigid airframe provides a stable platform for propulsion, avionics, and payloads, allowing precise attitude control and vertical takeoff, hover, and landing without the need for aerodynamic control surfaces. Autopilot is configured for the specifics of the airframe. Power and prefireal payloads are attached to this.

10.3. **Controller**

10.3.1. The UAV radio controller provides the primary command and control interface between the pilot and the aircraft. Pilot inputs are converted into digital control signals and transmitted over a radio-frequency link to the onboard receiver. These signals represent control axes such as roll, pitch, yaw, and throttle, along with mode selection and auxiliary functions. The receiver decodes the commands and passes them to the autopilot, which interprets them according to the active flight mode and applies appropriate control logic. The radio system also supports telemetry and failsafe functions, enabling command verification, signal integrity monitoring, and predefined aircraft behavior in the event of signal loss.

10.3.1.1. Remote Controller Configuration

10.3.1.1.1. The remote control system is programmable and may be configured to meet end-user operational requirements. Control channels, switches, and functions can be mapped to specific aircraft functions based on configuration and mission needs.

10.3.1.1.2. Generic controller configurations may be provided; however, switch labeling and function assignment are not standardized across aircraft configurations. Control layout, channel assignments, and switch functions may vary depending on aircraft model, payload integration, and autopilot setup.

10.3.1.1.3. Operators shall consult the aircraft manufacturer or approved documentation to verify correct switch assignments and control logic prior to operation.

10.4. **Ground Station**

10.4.1. The ground control station is a software-based command, monitoring, and configuration interface running on a laptop, tablet, or mobile device. It communicates with the aircraft via a bidirectional data link to display

real-time telemetry such as position, attitude, system status, and sensor data. The GCS allows the operator to configure aircraft parameters, plan and upload missions, select flight modes, and monitor flight performance during operation. It also provides logging, alerts, and diagnostic tools to support safe operation, post-flight analysis, and system troubleshooting.

10.5. **Battery and Power Distribution**

10.5.1. The battery serves as the primary onboard energy source, supplying electrical power to propulsion, avionics, and payload systems. Stored DC energy is distributed through a power management system that delivers high-current power directly to the motors and regulated power to sensitive electronics. Voltage regulation modules convert the main battery voltage to standardized levels, typically 24 VDC, 12 VDC, and 5 VDC, to support flight controllers, sensors, radios, and payload devices. This regulated distribution ensures stable operation, protects components from voltage fluctuations, and enables reliable system performance across varying load conditions.

10.6. **RID- UAS Remote Identification (Remote ID)**

10.6.1. Remote Identification (RID) is an FAA requirement that allows unmanned aircraft to broadcast identification and location information during operation. This aircraft is equipped with an integrated Remote ID module at the time of manufacture.

10.6.2. **Regulatory Basis**

10.6.2.1. 14 CFR Part 89 – Remote Identification of Unmanned Aircraft

10.6.2.1.1. <https://www.ecfr.gov/current/title-14/chapter-I/subchapter-F/part-89>

10.6.2.2. FAA DroneZone – Registration & Remote ID

10.6.2.2.1. <https://faadronezone.faa.gov>

10.6.3. **Owner / Operator Responsibilities**

10.6.3.1. The owner/operator is responsible for FAA registration, Remote ID serial number association, regulatory compliance, and operation in accordance with applicable regulations. This manual does not replace regulatory education.

10.6.4. **ATI Remote ID Integration**

10.6.4.1. ATI aircraft are delivered with an integrated DroneTag Remote ID module installed and configured at manufacture. ATI does not perform FAA account setup or owner registration.

10.6.5. **DroneTag Application**

10.6.5.1. Remote ID operational status is verified using the DroneTag application.

10.6.5.1.1. <https://help.dronetag.com/dronetag-app/>

10.6.5.2. DRI Module Manual

10.6.5.2.1. <https://help.dronetag.com/dronetag-dri>

10.6.6. Operational Verification

- 10.6.6.1. Remote ID status shall be verified via the DroneTag application prior to flight. Aircraft shall not be operated if Remote ID faults are indicated.

11. Battery Charging

- 11.1. Charging a battery is fairly simple and easy once practiced and understood to be a safe simple process. There are a few specific details to charging that will ensure the safety of the equipment property and people.
- 11.2. Disclaimer: !!Note Improperly setting up charger and battery can result in severe damage and bodily harm. Take precautions to ensure proper connections and settings of charge prior to charging. DO NOT LEAVE CHARGER UNATTENDED WHILE CHARGING!!
- 11.3. **Equipment:**
 - 11.3.1. **Power Supply-** Most chargers are DC powered, meaning they do not plug into an AC wall outlet. In order to charge indoors the charger needs AC converted to DC. That is the job of the power supply. Having an external power supply greatly increases the speed and performance of charging. Most AC/DC chargers perform poorly.
 - 11.3.2. **Charger-** This device takes the power from the power supply or an external DC power source and converts it to what is needed to charge the battery
 - 11.3.3. **Cables-** To connect batteries, balancer port, power supply and the like, we need wiring and connectors. These can come standard with the aircraft or can be altered by the end user.
 - 11.3.4. **Battery-** Power source for the aircraft. It has 2 sets of connections.
 - 11.3.4.1. 1st Connection is the main battery leads. Large gauge black and red power wires. This is how the aircraft both discharges to the aircraft and charges the battery.
 - 11.3.4.2. 2nd Connection is the balance tap. This small white connector with a few wires in it (depends on cell count) is used during charging for battery balancing and safety while charging.
 - 11.3.5. **Charging Procedure**
 - 11.3.5.1. **Cycle:** One use of a battery from fully charged to discharged.
 - 11.3.5.2. To charge a battery we need the components above. Please consult the charger manual as well as chargers may be different between users.
 - 11.3.5.3. Connect Power supply DC output to Charger DC input.

- 11.3.5.4. Connect Battery adapter charge cables to Charger (some chargers have dual ports, repeat for 2nd port)
- 11.3.5.5. Connect Battery balance tap extension board to charger
- 11.3.5.6. Plug power supply to wall or attach DC power leads of charger to a battery (12VDC).
- 11.3.5.7. Battery charger will power up.
- 11.3.5.8. Select the battery menu that corresponds to the battery type being charged. Most AgBot batteries are 22.2 VDC (6S), 7000mah.

NOTE: INCORRECT VOLTAGE SETTING CAN DAMAGE BATTERY AND CAUSE FIRE OR EXPLOSION - ENSURE PROPER CELL COUNT AND VOLTAGE ARE SET.

- 11.3.5.9. Connect battery charge leads to Charger battery adapters.
- 11.3.5.10. Connect battery balance tap to corresponding battery terminal.
- 11.3.5.11. Hold the Enter (2-4sec) button and the charger will respond with a tone and a change in display. This starts the charge.
- 11.3.5.12. The charger will check the battery and ask that you confirm the settings. If the settings are correct, push the enter button once. The display will show the current charge status. The timer will start, the milliamp counter will start to count and the battery is charging.
- 11.3.5.13. The charger knows when to stop the charge, if set correctly it will not over charge the battery. Users are suggested to monitor this from time to time for the first few charges.
- 11.3.5.14. If the charge doesn't stop or you wish to stop the charge simply hold the Enter button until the display shows the main menu.
- 11.3.5.15. Once the charger has completed its charge remove the battery from the battery adapter cables, and balancer connector.

!!NOTE: DO NOT DISCONNECT THE CHARGER BATTERY ADAPTER CABLES WHILE THE BATTERY IS STILL CONNECTED. A SHORT MAY OCCUR. ALWAYS DISCONNECT BATTERY FIRST AFTER THE CHARGE BEFORE DISCONNECTING CHARGER OR POWER SUPPLY CONNECTIONS!!

- 11.3.5.16. Repeat for additional batteries from step 8.
- 11.3.5.17. Once charging is done, disconnect the power supply from the wall, and disconnect power supply from the charger. Remove all cables and store the charger in a cool dry place.

11.3.6. Signs of damaged batteries:

- 11.3.6.1. If your battery has been over discharged it could be damaged. It will most likely suffer from loss of capacity not voltage.
- 11.3.6.2. Puffy battery: If you notice the sides of the battery swelling stop the charge or flight. Rapid swelling is a sign of a potential thermal runaway and could mean the battery can catch fire. If the battery is slowly swelling due to use, usually too much discharging, it will soften and swell. This isn't the same as rapid swelling.

- 11.3.6.3. **Hissing battery: DANGER** this could mean the battery is damaged, sometimes from a crash. Not often while charging. Hissing is the chemistry venting due to the battery package being compromised. **THIS MEANS THE BATTERY CAN CATCH FIRE AT ANY MOMENT.**

11.3.7. Battery Emergency:

- 11.3.7.1. If the battery is damaged due to crash or improperly charging it can spontaneously catch fire. If safe, try to disconnect battery from aircraft both electrically and physically, if you can get the battery away from the drone and property you can save the aircraft and other property from fire.
- 11.3.7.2. Try to have a metal container like an old ammo can or dutch oven to put the battery in so it doesn't catch anything around it on fire.
- 11.3.7.3. Use battery safe pouches if available for battery transportation and storage.
- 11.3.7.4. Fire extinguisher: Class D fire extinguisher only, ABC extinguishers do not work with Lithium fires. It can also corrode the drone. If an ABC extinguisher is used the aircraft is damaged beyond repair.
- 11.3.7.5. The battery must be monitored for 1-2 hours if damaged, this should be enough time for a fire to take place if it is going to. The next step is to discharge the battery with a charger. Then submerge the battery in a salt water bath for 24hrs. Then take the battery to a battery recycling facility for disposal.
- 11.3.8. **Battery Storage:** In order to get as many charging cycles out of a set of batteries it is critical to maintain them correctly.
- 11.3.8.1. If not in use, shelf batteries anywhere form 50%-75% capacity. **!!DO NOT CHARGE BATTERY THEN STORE THEM FOR OVER 2 WEEKS!!**
- 11.3.8.2. Discharge batteries either by flying them or using the Storage mode of the charger to put the battery in a storage configuration.
- 11.3.8.3. Do not store them in direct sunlight.
- 11.3.8.4. Do not store in a hot car for long periods of time.
- 11.3.8.5. Allow battery to cool before reuse
- 11.3.8.6. Do not check batteries on a domestic or international flight. Always take batteries on board with you and notify staff you have them to keep an eye on them should something go wrong.
- 11.3.8.7. Keep out of reach from children
- 11.3.9. **Suggestions for Battery longevity.**
- 11.3.9.1. In order to keep the battery living its longest it's critical to try and maintain some simple practices to get our money out of our battery.

- 11.3.9.2. Cycle batteries frequently. Batteries do not like just sitting around doing nothing; they need to be cycled at least 2 a month if possible. For some of our jobs this is no problem. But those who do not fly frequently will suffer from battery degradation.
- 11.3.9.3. Charge at 1 C if possible, avoid fast charging or fast discharging as much as practical.
- 11.3.9.4. Rotate battery usage, avoid using one battery all the time while one sits and isn't used as much, try to evenly cycle which batteries fly and sit.
- 11.3.9.5. Avoid fully discharging batteries. If you fly from 100%-0% capacity you will damage and stress the battery chemistry reducing performance and life cycles. Split flights up so one battery uses 50% of its capacity and the other battery uses 50% of its capacity. They will charge faster and it will increase the number of life cycles of the battery.
- 11.3.9.6. Allow the battery to cool down after a long flight especially in hot temperatures before charging. Do not charge the battery while it is hot.
- 11.3.9.7. If possible avoid charging to 100% all the time. If you can fly on half the battery it is suggested to charge to 85% and discharge to 25%. This is the best charging performance. It can take the charger the same time to go from 25%-85% as it takes to go from 85% to 100%.

Glossary of Terms

- AGL - Above Ground Level.
- ATC - Air Traffic Control
- COA - Certificate of Authorization
- Ceiling - Broken or overcast clouds
- DA - Density Altitude - Air density given as a height above mean sea level.
- DroneZone – FAA web portal for UAS registration and Remote ID compliance.
- EKF - Extended Kalman Filter
- FAA - Federal Aviation Authority
- FCC - Federal Communications Commission
- FISDO - Flight Standards District Offices
- GCS - Ground Control Station.
- GPS - Global Positioning System
- IMU - Inertial Measurement Unit
- LAANC - Low Altitude Authorization and Notification Capability
- LZ - Landing Zone
- METAR - Aviation Weather Report.
- NOTAM - Notice to Airmen. A notice released by an aviation authority to alert PICs of potential hazards on a flight route, or at a location that could affect the safety of the flight.
- NTSB - National Transportation Safety Board
- Part 89 – FAA regulation governing Remote Identification of Unmanned Aircraft.
- Part 107 - Current FAA regulation governing commercial UAS operations in USA.
- PIC - Pilot In Command. Responsible for all flight operations.
- PWM - Pulse width Modulation
- RF - Radio Frequency
- RID - FAA mandated system for broadcasting uncrewed aircraft identification and location data.
- RTL- Return to Launch
- UAS - Uncrewed Aerial System.
- UAV - Uncrewed Aerial Vehicle

- Visual Observer (VO) - Responsible for monitoring the operational area to ensure that there are no hazards that may endanger the flight or people not part of the UAS flight operation team.
- VLOS - Visual line of sight.

Appendix A

Requirement for Visual Observer - VOs will be briefed by PIC prior to all flights. The VOs primary responsibility will be to maintain Visual Line of Site with the UAS and assist the PIC.

Aircraft:

Model	Brand	Model #	Approx. Manufacture Date	S/N
BOT	ATI			

Payload & Communications

Payload control and monitoring links depend on exact payload used; which includes a secondary 2.4 GHz transmitter/receiver for motion control and real-time video transmission feed.

Operating Frequencies - 2.400-2.483 GHz; 5.725-5.825GHz; 900MHz

Request of NOTAM

A distant (D) NOTAM must be issued when unmanned aircraft operations are being conducted outside of the blanket 200-foot COA. This requirement should be accomplished:

(a) XXXX or NOTAM issuing authority,

or

(b) By contacting the NOTAM Service Station at XXXXXX

not more than 72 hours in advance, but not less than

24 hours prior to the operation, unless otherwise authorized as a special

provision. The issuing agency will require the Name and address of the pilot filling the NOTAM request, Location, altitude, operating area, Times and purpose.

Submission of Plan of Activities

At least three (3) days before

Name and phone number of the operator for the UAS

Name and phone number of the person responsible for the on-scene operation of the UAS;

Make, model, and serial number or N-number of the UAS to be used;

Name and certificate number of the UAS PICs involved

A statement that the operator has obtained permission from property owners and/or local officials to conduct flights made available to the inspector upon request;

A description of the activity, including maps or diagrams of any area, city, town, county, and/or state over which will be conducted and the altitudes essential to accomplish the operation.

Additional Operational Guidelines

Standard BOT Aircraft Preflight Power up procedure:

1. Verify airspace of operation verify flight plan airspace authorization LAANC
2. Remove aircraft from the case and unfold arms, make sure the C-clip that holds the arm is not cracked or broken.
3. Extend landing gear legs and ensure locking mechanisms are secure.
4. Install props, make sure not to force threading of the propeller, if the propeller does not want to thread make sure you're installing the correct propeller per rotation of the motor. Props should easily thread and tighten, do not over tighten the propeller.
5. Ensure dome and GPS antenna are correctly attached and orientated and that dome will not depart aircraft during flight.
6. Install and secure payload.
7. Install and secure Batteries, make sure they are secure and will not get loose after turbulence or vibration. Make sure battery wires and connectors will not interfere with the propeller, min distance of object to propeller is .5 inch.
8. Ensure aircraft batteries and controller/GCS batteries are charged for flight.
9. Attach antennas if removed.
10. Power up the ground station, connect data link cables to controller or computer.
11. Power up controller, ensure switches on controller are in the default startup position.
12. Open applicable RID app, connect to drone, verify RID status is good and no faults, verify authorization of planned flight.
13. Position aircraft in a good location for takeoff and landing, make sure no dirt rocks or debris will get kicked up during takeoff and landing.
14. Power up one aircraft battery and look at lights and listen to tones for proper boot up.

15. Once boot up is complete, plug in the second battery, make sure battery connections are secure and not easily unplugged or too difficult to plug in.
16. Press Motor Arm Safety Switch if intending to run motors, if not arm then disarm so ESC don't emit a constant tone.
17. Verify controller connection to aircraft, commence connection of aircraft to GCS laptop or tablet. Verify correct information is present on GCS.
18. Load mission on aircraft if created, verify on Flight Data page mission is present and correct.
19. Turn on video equipment and verify video and or payload control is correct.
20. Set any camera settings, calibration or reflectance panel capture is performed.
21. Verify enough memory for the mission is present on the SD card of the camera.
22. Verify the area is clear for launch, verbally announce takeoff or landing loudly so people can hear.
23. Arm autopilot using controllers and prepare to fly aircraft, keep those fingers on the control sticks until stability is verified. Select flight mode and commence flight.

After landing recovery:

1. Make sure the landing area is clear and announce landing.
2. Fly aircraft manually or in an auto land flight mode to a position directly over the intended landing area one aircraft diameter above the landing spot. Once stable and no lateral movement is noticed, the final touch down decent.
3. Once on the ground bring the throttle to lower most mid stick on the throttle stick and wait for the engines to go to idle.
4. Once engines are at idle you can disarm moving the stick to the bottom left or simply keep the throttle center and all the way down and engines will disarm after 15-30 sec. (if by lowering throttle the engines do not go to idle do not use the throttle stick to disarm as this could cause the aircraft to tip over, the aircraft will idle the engines if it has verified it has landed on the ground. Keep throttle low and center and wait until it disarms itself)
5. Once propellers have stopped, approach the aircraft and either power off using battery connectors or disarm the motors.
6. If changing payload please power off as most payloads cannot be installed or removed with power applied to aircraft.

Appendix B:

ICAW

Instructions for Continued Airworthiness

Airframe: Quadcopter tractor motor type. Main material types are carbon fiber, nylon, ABS, Aluminum. Most all these materials are on condition inspection. Most pre and post flight inspections will cover most of the airframe and its parts current condition. If an aircraft has suffered any impact from flying or handling please inspect all parts as below.

It is advisable that a more thorough inspection of airframe components be performed every 3 months or 30 battery cycles whichever comes first.

The frequency of inspection is directly related to the amount of use the aircraft gets. The more you fly the more you need to inspect. The hotter or colder the conditions the more the stress on the airframe. Also dusty or wet conditions add to wear of parts and components.

Carbon fiber parts need to be inspected for cracks or stress, use a shop rag and wipe the surface of the carbon parts, if the rag gets hung up or caught on any carbon surface inspect the area, usually a piece of the rag will get caught on the small carbon fibers if they are damaged.

Nylon and plastic parts should be inspected for cracks, stripped out hardware, wear and or heat damage. Look for discoloration and warping as that is what plastic does when overheated. Nylon cannot be glued, it is advised to replace nylon parts if damaged. ABS can be field repaired using Acetone.

Hardware on the aircraft is a combination of metric 2.0mm 2.5mm 3.0mm and 4.0mm These fasteners often use blue loctite for security, loctite can adversely affect the durability of plastic. Be cautious when replacing hardware with loctite close to plastic parts, use loctite sparingly and be sure to remove excess. The aircraft also has many nuts installed, mostly 3mm nylock nuts,



make sure at least a thread of the screw protrudes from the screw so the Nylon lock ring has contact with the screw. Other nuts may need loctite and or a lock washer if not using the self locking nylock nuts.


Aluminum parts inspect for dings, dents, bending, or cracks, corrosion. Repair or replace as required.

Landing gear are designed to keep the payload from touching the ground, they also function as a way to absorb a rough landing and are sacrificial. Make sure the gear locks into place when down and when retracted stays in place and is not loose, gear should remain in a position set by the handler and not swing freely, adjust as necessary.

Battery mounts are on condition inspected. The intent of the battery holder is similar to the landing gear, they are meant to break free in the event of a crash. Make sure the battery is firmly attached to the mount. Make sure the velcro strap is in good condition, if you see fraying, or the velcro doesn't hold as it should then replace the strap. Check for secure hardware and that the plastic is in good condition. Silicon tape is used as a surface for the battery to adhere to while attached. If the silicon tape is exposed to dust and debris it can reduce the stick the tape has and not keep the battery from sliding on the battery mount, please replace the silicone tape as needed to keep the battery from sliding while strapped to the mount.

Arms and Engine Mounts are on condition, if a hard landing or accident while ground handling has occurred please inspect the engine mount for proper orientation or damage. It is important the motor mount be parallel to the upper center plate of the airframe, the human eye can detect an engine mount that has rotated on the arm, simply loosen the engine mount screws a little, rotate the motor mount until the motor is level to the center plate and retighten the screws. This airframe has foldable arms however this feature introduces areas of note to pay attention to if used frequently. The arms pivot at its root, this is done using screws, if the arms are folded it can loosen these screws, please keep a close eye on these screws as the arm can come loose over time. See diagram.





Payload Mount Rail: are a key function on mounting external payloads to the aircraft, it is a simple Picatinny rail that when coupled with the quick disconnect make it easy to attach and move payload articles. Make sure the rail is securely fastened and that the quick release is correctly attached. If you feel play in either the quick release or the mounting of the rail, inspect and adjust as necessary.

Engine and PowerTrain:

Motors: are on condition inspection, items to inspect are bearings for noise or friction. Play in the vertical axis of the motor, over time the collet at the bottom of the motor can come loose and cause the upper part of the motor to move away from the bottom part, if this occurs please resecure motor shaft collet per KDE manual. Get used to how it feels to move a motor by hand, we have multiple motors on the airframe and they all should behave the same way when manipulated. Bearings can wear out over time especially if in hot dusty climates, please routinely oil the bearings of the motor when needed.

ESC's: (electronic speed controller) drive the motors so they absorb the electrical loads of the engine and most likely suffer damage if the motor is suddenly stopped or prolong heavy loads are exerted. It is hard to inspect ESC's and usually it is recommended they are replaced if crashed. Contact ATI for more information.

<https://www.kdedirect.com/collections/uas-multi-rotor-brushless-motors/products/kde4012xf-400>

Propeller/Rotor: Propellers are carbon fiber and on condition inspected. If damage is suspect and a prop strike has occurred please inspect the propellers for cracks, out of balance or track, and mounting defects. Use a shop rag to wipe the whole surface of the propeller, if the rag catches on any carbon inspect further. Look for pieces of the shop rag on the propeller, if the carbon is compromised it will snare the rag. Make sure the propeller is tracking. Look for vibration coming from the engine by observing the aircraft in flight and looking at parts such as the landing gear leg for shaking or vibrating.

Propeller mounts are aluminum, make sure the threads are in good condition and not showing signs of stripping. Some propeller mounts can bend if damaged so if you suspect a prop strike inspect the propeller mounts and hubs for damage. Cracks originating from center to 4 inches are considered unrepairable and unserviceable. The only portion of the propeller that can be serviced is the tips. Contact ATI for service recommendation.

Some AgBots have three or two blade propellers that fold and need to be unscrewed to remove. If you have one of these propellers then you need to check blade tension on each blade relative to the blade holder before each flight. The blade holder is aluminum and it can change tension due to temperature and vibration. Ensure each propeller blade has the same tension, as a difference in tension can cause a blade to swivel more than the adjacent blade causing an out of phase (non equal degrees of separation, ie. 3 blade is 120deg, 2 blade is 180deg). Out of phase can cause vibration. The blade tension should be enough to eliminate play. When you unfold the blades they should stay in place and not loosely move on their own. It should require a small amount of effort to move or fold a blade.

If you see the end of your landing gear vibrate this can indicate a propeller that is out of balance, track or phase, OR something loose like an arm, engine mount etc... Please land and inspect propeller and airframe hardware and structure.

Power Distribution: The top plate of the aircraft is a PCB board designed to take battery power and distribute it to each arm and to the voltage regulation for the autopilot and accessory equipment installed on aircraft. DO NOT Drill holes in the top center plate of the aircraft as you could short out power and ground. Any cracks or bending of the top center plate deems it unsafe for operation and should be replaced.

Power Regulation: Each aircraft is equipped with 2 5VDC and 1 12VDC power regulators that get their power from the PBD. 1 5VDC is dedicated the power

Autopilot/Sensors: Autopilot is Pixhawk 1, Pixhawk 2.1, Cube Black or Cube Orange. Their hardware runs Ardupilot firmware. Inspect on condition mounting hardware and cables and connectors. Pixhawk 1 does not have locking connectors so ensure they are connected properly and secure. Ensure wire bend radius is not over 1.5 times the diameter of the wire gauge. Ensure servo connectors on the back of the autopilot are secure, they are not locking. Cube autopilots have locking connectors so make sure they are seated. Sometimes individual wires at the connector can become unseated, you will see the metal pin starting to protrude out the back of the connector. If you see pins coming out of connectors contact ATI for repair procedures.

Antennas depend on your specific radio controller, telemetry, and video link equipment integrated at the time of purchase. No matter what the configuration of your aircraft, antennas must be installed correctly before power up. Most Radio Frequency gear and equipment cannot run correctly without the antenna installed and can cause substantial damage if operated without the antenna. Inspect antennas for damage and security, also inspect the antenna mounts for damage or security. Some antenna connections have different polarity connections. Pay close attention to the type of coax connection as it can be possible to put the wrong antenna on the wrong coax disconnect. Remote ID hardware is embedded and inspected on-condition. Antennas associated with Remote ID shall be inspected for security and damage during routine maintenance.

Payloads: There are many different types of payloads the aircraft can carry. From cameras to hooks, winches, or object releases, payloads have their specific requirements. However most payloads all require power to operate and therefore must be installed and removed from the aircraft without power applied. This is especially true for cameras. Make sure if you are going to install your payload that power is off when installed or removed. Make sure your payload is properly secured and connected. Make sure your payload is within the operating range of the airframe. It is possible to reduce battery weight if a heavier payload is required, just know that endurance and agility may be affected so fly the aircraft carefully when at maximum payload capacity is used. Contact ATI if you plan on altering the payload of the aircraft dramatically.

Appendix C:

Components and Limits

Purpose: Below is a list of components and limitations for the AgBOT quadcopter. These limits are based on conditions of ambient temperature, pressure, at sea level. Conditions directly impact aircraft performance so take into consideration the current environment and adapt. If this is a new location, and the current conditions are new, please take the time to consult manuals, documentation, and the manufacturer for guidance.

Airframe Configuration VTOL Quadcopter Material Carbon Fiber Frame, Nylon, ABS

Motor: KDE 4012 400KV, ESC KDE 35 Amp

Propeller: TRI KDE 15.5", Dual KDE 15.5", Dual 16x5" Tiger Prop

Flight Controller: Ardupilot, Cube, Here GPS, Here2

Ground Control: PC, Android, iOS.

Flight Radio: Taranis X9D, Here Link

Operating Temperature: -10 to +40 Deg C (battery limitations override temperature rating of airframe)

Operating Freq: 5.8 GHz, 2.4 GHz, 900 Mhz

Operating Freq Range: 1 mile to 26 miles Depending on configuration.

Weight (incl. sensor and battery) 4.7 kg (10.4 lbs)

Length (Motor Center to Center) 70cm (27.5 in) Height 40cm (15.75 in)

Case Dimension 112 x 40.9 x 35.5 cm (44.16 x 16.09 x 14 in) Loaded Case Weight 24.3 kg (53.6 lbs)

Battery Dual 6S 7000 mAh, 25C, 25 Volt, Available 5VDC regulated and 12VDC Regulated



Charger 12-24 Volt 500W 2 Chan Multi Charger: Power supply 115, 240 VAC input 12VDC 40 Amp Output

Flight Time (no payload) 30 Min with reserve.



Appendix D:


Wiring Diagrams and Schematics


Aircraft side of power and camera disconnect




*









BOT AIRCRAFT CONTROLLER LAYOUT



SA= RTL (Return to Launch)	SE= N/A, Cam Mode, Pan, Stow
SB= Cam Trigger/Start Stop Rec	SF= Lights
SC= N/A, IOC, Alternate Mode	SG= N/A, Cam Zoom
SD= MODE Loiter	SH= N/A
ALT Hold	RS= N/A
Auto	S1= N/A, Cam Pan
LS= Cam Tilt	S2= N/A
Long Push Page Button=Telem	Exit=Home screen

Aerial Technology International LLC

Unmanned Aerial System (UAS) Service & Product Use Agreement

This Service and Product Use Agreement (“Agreement”) is entered into as of , 2026, by and between Aerial Technology International LLC (“ATI”), an Oregon Limited Liability Company, and ** _____ (“UAS Purchaser”)**, purchaser of unmanned aerial system (UAS) aircraft, components, and related services.

RECITALS

WHEREAS, ATI designs, sells, integrates, and services unmanned aerial system (UAS) aircraft and components;

WHEREAS, UAS Purchaser desires to purchase and operate such systems;

WHEREAS, ATI requires UAS Purchaser to be familiar with the proper and safe use of such systems;

NOW, THEREFORE, in consideration of the mutual covenants contained herein, the parties agree as follows:

SECTION 1. SAFETY AND OPERATION

1.1 Training Requirement

UAS Purchaser agrees to participate in and review any introductory training provided by ATI prior to operating the system.

1.2 Additional Assistance

UAS Purchaser agrees to seek additional instruction or assistance from ATI when necessary to ensure safe and proper operation.

1.3 Safety Warning

UAS systems are complex aircraft systems. Improper operation may result in serious injury, death, or property damage. ATI does not guarantee error-free performance of hardware or software.

1.4 Use at Own Risk

UAS Purchaser acknowledges that operation of the equipment and associated systems is conducted at their own risk.

1.5 Safe Operating Environment

UAS Purchaser agrees to avoid operation over non-participating persons or property unless authorized and conducted in accordance with applicable regulations.

1.6 Regulatory Compliance

UAS Purchaser is solely responsible for understanding and complying with all applicable local, state, and federal laws and regulations, including those of the Federal Aviation Administration.

1.7 Safe Operation Practices

UAS Purchaser agrees to exercise sound judgment and adhere to safe operating practices at all times.

1.8 Maintenance and Pre-Flight Checks

UAS Purchaser agrees to conduct pre-flight inspections prior to each operation and perform ongoing maintenance in accordance with manufacturer guidelines and ATI recommendations.

1.9 Operator Competency

UAS Purchaser acknowledges that operation of UAS systems requires technical knowledge and experience. ATI is not responsible for the actions of inexperienced or unqualified operators.

SECTION 2. WARRANTIES

ATI warrants that all goods provided shall be free from material defects at the time of delivery and shall conform to agreed specifications.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

No warranties extend beyond those expressly stated in this Agreement.

SECTION 3. LIABILITY AND RISK

3.1 No Assumption of Liability

ATI assumes no liability for injury, damage, or loss associated with the use of UAS systems.

3.2 System Performance

ATI does not guarantee uninterrupted or error-free operation of any system, including hardware, software, or integrated components.

3.3 Responsibility for Adjustments

UAS Purchaser is solely responsible for all system configurations, parameter adjustments, and operational settings.

3.4 Liability for Damages

UAS Purchaser assumes full responsibility for any damage to persons or property resulting from operation of the system.

3.5 Improper Use

UAS Purchaser assumes all liability arising from improper, unsafe, or unlawful use of the system.

3.6 Insurance

UAS Purchaser is strongly advised to maintain appropriate liability insurance covering UAS operations.

3.7 Assumption of Risk

UAS Purchaser assumes all risks associated with the use of the system and determines its suitability for the intended application.

3.8 Limitation of Liability

To the fullest extent permitted by law, ATI's total liability shall not exceed the amount paid by UAS Purchaser for the product or service.

3.9 Exclusion of Damages

IN NO EVENT SHALL ATI BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES, INCLUDING LOSS OF PROFITS OR BUSINESS INTERRUPTION.

3.10 Indemnification

UAS Purchaser agrees to indemnify, defend, and hold harmless ATI and its officers, employees, and representatives from any and all claims, damages, liabilities, and expenses (including attorney fees) arising from use of the system.

SECTION 4. GOVERNING LAW

This Agreement shall be governed by and construed in accordance with the laws of the State of Oregon, without regard to conflict of law principles, except where superseded by applicable federal law.

SECTION 5. SEVERABILITY

If any provision of this Agreement is found to be invalid or unenforceable, the remaining provisions shall remain in full force and effect.

SECTION 6. ENTIRE AGREEMENT

This Agreement constitutes the entire agreement between the parties and supersedes all prior discussions, representations, or agreements.

SECTION 7. ACCEPTANCE

By signing below, UAS Purchaser acknowledges that they:

- Have read and understand this Agreement
- Accept all risks associated with UAS operation
- Agree to complete ATI training prior to operating the system
- Agree to release and indemnify ATI from liability arising from use of the system

A signed copy of this Agreement is required prior to delivery or operation of any ATI UAS system.

UAS Purchaser Signature: _____ Date: _____

Printed Name: _____

ATI Representative Signature: _____ Date: _____

Printed Name: _____

Limitations

Operation of ATI-manufactured or custom aircraft is subject to regulatory, environmental, and configuration-specific limitations. The owner/operator is responsible for ensuring compliance with all applicable laws, regulations, and operational constraints.

Liability Statement – End of Document

Add as final section, no heading hierarchy change:

Liability Notice

ATI aircraft systems are intended to be operated by trained and qualified personnel. The owner/operator assumes responsibility for regulatory compliance, safe operation, maintenance, and use of the aircraft and associated equipment. ATI assumes no liability for misuse, unauthorized modification, or operation outside applicable regulations or published guidance.